




THIS DOCUMENT PROPRIETARY TO TITAN AIRCRAFT, AND IS NOT TO BE USED, CIRCULATED, REPRODUCED, COPIED, OR DISCLOSED IN ANY MANNER WITHOUT PRIOR WRITTEN PERMISSION OF AN AUTHORIZED OFFICIAL OF TITAN AIRCRAFT.



$\triangle C$ SIDE VIEW OF CENTER SECTION RIB # 2

REVISIONS

E.C. NO.	REV.	DESCRIPTION	BY	DATE
	A	RELEASED DRAWING	SH	2/08
0669	B	DIMENSION CHANGED	SH	4/08
0824	C	NOTES CHANGED	SH	12/08

$\triangle C$ NOTES:

- BE CAREFUL NOT TO DRILL THE FUEL TANKS WHEN DRILLING HOLES FOR MOUNTING BRACKETS.
- WHEN POSITIONING THE AFT RUDDER PEDALS, MEASURE 11" BACK FROM THE FRONT OF THE FOOT WELL. THIS WILL BE THE CENTER OF THE MOUNTING BRACKETS BOLT. BOND AND RIVET THE MOUNTING BRACKETS IN PLACE USING (4) SD44BS RIVETS ON TOP & (4) SK45BS RIVETS ON THE INSIDE OF MC07-329 PER FOOTWELL.
- WHEN THE AFT RUDDER PEDAL ASSEMBLIES ARE IN THE NEUTRAL POSITION THE TOE OR TIP OF THE BRAKE PEDALS SHOULD BE APPROX. $2\frac{1}{2}$ " ABOVE THE FLOOR.
- WHEN FOLDED BACK IN THE STOW POSITION THE FOOT RAIL OR SHAFT SHOULD BE APPROX. $\frac{3}{8}$ " FORWARD OF THE BACK WALL OF THE FOOT WELL. IF YOU ARE INSTALLING THE OPTIONAL BRAKES, YOU WILL HAVE ABOUT $\frac{1}{8}$ " CLEARANCE BETWEEN THE AFT EDGE OF THE BRAKE PEDAL AND THE AFT TOP EDGE OF THE FOOT WELL.
- WHEN THE AFT RUDDER PEDALS ARE IN THE STOWED POSITION THE REAR SEAT PASSENGER IS UNABLE TO APPLY BRAKES AS THE TIP OR TOE OF THE BRAKE PEDAL IS VERY CLOSE TO OR TOUCHING THE FLOOR.



TITAN AIRCRAFT SUPPLY
1419 STATE ROUTE 45 SOUTH
AUSTINBURG, OHIO 44010

DETAIL NAME AFT RUDDER PEDAL FOOT WELL INSTALLATION

DRAWN
S. HENDERSON

DATE
2/20/08

CHECKED
RI

DATE
2/20/09

APPROVED
KORY B.

DATE
7/2/09

SCALE 1"=1"

PART NO.

ASSEMBLY NAME

PART NO.

DRAWING NO.

CS17

DRAWING NO. **B T51-08-INS-1713-C**