

NOTES:

- MOUNT RUDDER PEDAL TANGS TO RUDDER PEDALS USING AN3-11A BOLTS AND AN365-1032 NUTS.
- CLAMP RUDDER PEDALS TOGETHER TO ASSURE THEY REMAIN IN THE NEUTRAL POSITION.
- CLAMP THE RUDDER TO THE VERTICAL STABILIZER TO ASSURE IT REMAINS IN THE NEUTRAL POSITION.
- ROUTE RUDDER CABLES THRU FUSELAGE AS SHOWN ON DRAWING B92-INS-0190.
- NICO PRESS RUDDER CABLES TO RUDDER CABLE TANG.



DRAWN

CHECKED

APPROVED

J. PRESTON

J. WILLIAMS

R. INGLE

TITAN AIRCRAFT SUPPLY 1419 STATE ROUTE 45 SOUTH AUSTINBURG, OHIO 44010

	DETAIL NAME	RUDDER CABLE INSTALLATION
DATE 5 /17 /02	SCALE N/A	PART NO. N/A
5/13/92 Date	ASSEMBLY NAME	SINGLE SEAT FUSELAGE ASSEMBLY
3/24/01	PART NO.	N/A DRAWING NO.
DATE 3/24/01	drawing no. B	92-INS-0194-B