NOTES:

- POSITION ALUMINUM GAP SEAL ONTO WING AND FUSELAGE AS SHOWN. THE ALUMINUM GAP SEAL MAY NEED TO BE SLIGHTLY BENT FOR A BETTER FIT.
- DO NOT LET THE ALUMINUM GAP SEAL OVERLAP THE FRONT DOOR.
- DRILL MOUNTING HOLES IN PATTERN SHOWN THRU GAP SEAL AND WING. DRILL WITH #30 DRILL (.1285 DIA). DO NOT DRILL THRU FUSELAGE.
- RIVET WITH AD42BS RIVETS (1/8 DIA X 17/64 LONG).



