

THIS DOCUMENT PROPRIETARY TO TITAN AIRCRAFT, AND IS NOT TO BE USED, CIRCULATED, REPRODUCED, COPIED, OR DISCLOSED IN ANY MANNER WITHOUT PRIOR WRITTEN PERMISSION OF AN AUTHORIZED OFFICIAL OF TITAN AIRCRAFT.

USING AN3 ANCHOR NUT AS GUIDE, DRILL (4) #41 HOLES AND RIVET ANCHOR NUTS TO STAND OFF WITH SD32BS RIVETS.



FORWARD
END

TG00-124 RIGHT
TG00-125 LEFT

FOR MECHANICAL DRUM BRAKES USE:
TG97-96 R
TG97-96 L
FOR HYDRAULIC BRAKES USE:
TG02-192 ©
HYD. WHEEL PANT BRACKET

IF DESIRED, BOTH RIVETS
CAN BE PLACED ON THE
UNDERSIDE FOR COSMETICS

CUT TO LENGTH
TG00-128 R & L

TG00-126 RIGHT
TG00-127 LEFT

THIS AREA MUST
BE NOTCHED OUT
TO ALLOW PROPER
INSTALLATION OF
SPINDLE.

SEE DRAWING B97-INS-0865 OR 02-INS-1366 FOR
DETAILS ON INSTALLATION.

TITAN AIRCRAFT SUPPLY
1419 STATE ROUTE 45 SOUTH
AUSTINBURG, OHIO 44010

DETAIL NAME DELUXE WHEEL PANT PARTS PREPARATION

SCALE N/A PART NO.

ASSEMBLY NAME DELUXE WHEEL PANT INSTALLATION

PART NO. DRAWING NO.

DRAWING NO. *B 97-INS-0893-C*

DRAWN	K. BOHRER	DATE	8-14-97
CHECKED		DATE	
APPROVED		DATE	

USING AN3 ANCHOR NUTS AS A
GUIDE, DRILL (4) #41 HOLES AND
RIVET ANCHOR NUTS TO STAND OFF
WITH SD32BS RIVETS.

TG97-99

